



Honda F2/F3 Foot Control Kit P.N. 202101

Installation instructions

1. Remove clevis pin attaching the rear brake master cylinder to the brake lever.
2. Remove the rear brake master cylinder and let hang free.
3. Unplug the rear brake light switch from the harness & remove the right foot control assembly.
4. Mount the right foot control assembly supplied in the kit to the frame using the stock screws.
5. Mount the rear brake master cylinder to the inside of the foot control assembly using the stock fasteners.
6. Attach the brake master to the brake lever using the stock clevis pin.
7. Proceed to the left side of the motorcycle and remove the stock shift rod by loosening the jam nuts and unscrewing it from the shift lever.
8. Remove the left foot control assembly.
9. Install the left foot control assembly supplied in the kit using the stock mounting screws.
10. Install the shift rod supplied in the kit using the stock jam nuts. For reverse shift application on F3 models and standard shift application on F2 models the shift rod will have to be shortened to a length between 220mm and 215mm depending on the rider's desired foot position.
11. Adjust both brake & shift levers to suite your riding style and double-check all your fasteners.

This and all Attack Performance products should be installed only by a qualified service technician.